

## ステージ楽器

### ■Guitar Amp

Marshall / JCM 2000 (HEAD)×1  
 Marshall / JCM 900 (HEAD)×1  
 Roland / JC 120 (COMBO)×1  
 Marshall / 1960 (BOTTOM)×2

### ■Bass Amp

Mark Bass / Little Mark3  
 Ampeg / SVT-810E (BOTTOM)×1

### ■Drum Set

Pearl / VISION (MAPLE)  
 :22" Bass/12" Tom/13" Tom/16" F Tom/14" Snare  
 SABIAN / B8 :14" HH / 16" /18" /20" Ride  
 Pedal/Throne/Stands/

### ■Others

KORG / X3(61 鍵)×1      Keyboard stand×2

## PA 機材

### ■Mixer

BEHRINGER-X32

### ■Front Speaker

JBL×4(2445J/E140)  
 Peavey / 15" ×2(Sub Woofer)

### ■Monitor Speaker

Electro Voice / FM1502ER×4(Front)  
 Electro Voice / FM1502ER×1(Dr)+2(SUB)

### ■EFFECT

YAMAHA SPX990×1

### ■Power Amp

Front Speratek 用 : YAMAHA / P3500s:1  
 Classic Pro / CP1200:1  
 CREST / CA2:1

Sub Woofer 用 : CREST / CA6:1

Monitor 用 : YAMAHA / P4500:2

### ■Cross Over

dbx / 234xs

### ■D.I

DOD / 275(Active)×5 / RADIAL PRO DI×1

DOD / 265(Passive)×1 / RADIAL PRO D2×1

### ■MIC

SHURE / SM58×5

SHURE / SM57×6

SHURE / β57×1

SHURE / β52-A×1

SHURE / PG52×1

SHURE / β58×1

CUSTOM TRY / CM2000×4(スイッチ付)

AUDIX / F10×1

SENHEISER / e-945×1

SENHEISER / e-901×1

Classic Pro / CM58DR×5

AUDIO TECHNICA / AE6100×2

BEHRINGER / C-2×2

E.V PL35×2

## 照明機材

### ■Dimmer

Lite-Puter(12ch×20A) DX-1220D

### ■Opetator

ADJ / SCENE SETTER 12×2 Scenes  
 12Chase×4Page

### ■Other

SMOKE:STAGE EVOLUTION SM700

STROBE:American DJ / MEGA FLASH DMX

MIRROR BALL:American DJ / MB20

DISCO LIGHT:American DJ / AGGRESSOR TRI LED

### ■Par 56(300W)

Back / 18 灯 / 5 回路

Side / 8 灯 / 3 回路

### ■Front Pin

3 灯 / 3 回路

### ■ミニブル

2 灯 / 1 回路

ステージ楽器用電源 :20A×3 回路 (アース付)  
 ステージ寸法等は別紙平面図にて。

Live House NARA NEVERLAND

〒630-8001 奈良市法華寺町122-1 / ☎.fax 0742(36)2431

E-mail naraneverland@yahoo.co.jp

最終更新日 : 2017年11月30日